

# LOVE BIRD



**MyLibido**  
MAKE IT HAPPEN

## USER MANUAL

If have any questions, please feel free to contact us via:


[www.mylibido.com.au](http://www.mylibido.com.au)

## Product Description

This product has an elegant appearance and perfect touch. It has super strong vibration and multiple vibration modes.

1. Material: Food-grade silicone
  2. Max noise: ≤80db
  3. Battery: 170mAh rechargeable lithium battery
  4. Power: USB 5V 150mA DC charging, charging time about 2H, use time about 1H.
  5. Waterproof Rating: IPX7.
- Package: 1 x Massage ball, 1 x USB charging cable, 1 user manual

## Instruction




- 1 -

## Charging Guide

- (1) Put the DC charging plug into the hole in the motor part to charge. (output: 5V=1A or 5V=1.5A).
- (2) When product is charging, the LED will be flashing.
- (3) When a solid light appears, charging is complete.

\*When being charged, the toy must be in shutdown state and cannot be used



- 2 -

## Usage

1. Download and install "Mu Se Life" APP

### IOS system

1. Search for "Mu Se Life" in App Store, download and install.

2. Scan the QR code with your mobile phone, and follow the prompts to download and install the "Mu Se Life" APP.

### Android system

1. Scan the QR code with your mobile phone and follow the prompts to download and install the "Mu Se Life" APP.



QR code


- 3 -

## II. Register and log in

1. Click the "Mu Se Life" icon to enter the APP. Please register for the first login.
2. Click on "New user registration" and complete the registration with your e-mail address.
3. After registering, enter the account and password to log into the APP.

\* If the email cannot get the verification code:


1. Please check your spam folder.
2. Please try a different email address.
3. Contact our customer service.



- 4 -

## III. Device binding

1. The customer needs to bind the device after logging in for the first time.
2. Click "+", the device binding scan box will appear.
3. Scan the device identification code on the product packaging box or manual, and the product icon will be displayed on the APP after the scan is successful.
4. If the customer has purchased several products, please repeat the above 2-3 steps to complete the binding of other products.
5. Long press the device icon to delete the device and modify the device name.
6. After the device is deleted, if the customer wants to restore it, he needs to scan the device binding code again.



8422131013525

Device identification code

- 5 -

## IV. Equipment connection


First turn on the switch of the device, and then click the device icon in the APP. If the Bluetooth of the mobile phone is not turned on at this time, a prompt box of "Mu Se Life" wants to turn on the Bluetooth" will appear. After clicking Allow, the mobile phone will automatically turn on the Bluetooth (iPhone Manually turn on the Bluetooth switch). At this time, the device and the phone begin to establish a connection, and enter the device control interface after the connection is successful.



- 6 -


## V. Mode introduction

1. Solitary mode: Click any icon on the APP, and the device will start the corresponding vibration frequency. At the same time, the icon on the APP will flash, click this icon again, the device will stop vibrating and enter the standby state, and the APP icon will stop flashing.



- 7 -

**2. Music mode:** Click on the music mode or slide the operation interface of the APP to enter the music mode. The APP will automatically search for the music player in the mobile phone. If you click on a music player to play music, the device will vibrate as the music changes. If you want to stop the music mode, click or slide to other control interface.



**Note:**  
If the sound of the mobile phone playing music is too low, it may not be able to drive the device to vibrate. Apple phones can only use the music player that comes with the system.



Music is empty in iTunes, Please add m...

— 8 —

**3. Swipe mode:** Click on the swipe mode or slide the operation interface of the APP to enter the swipe mode. Tap "+", swipe your finger on the phone screen, and the device will vibrate with the change of the swipe. You can keep the vibration mode for next use.



— 9 —


**4. Shake mode:** Click on the shake mode or slide the operation interface of the APP to enter the shake mode, and the device will vibrate according to the shaking rhythm and amplitude of your phone.



Shake your cell phone.

— 10 —


**5. Interactive mode:**  
a. Tap the interactive mode or slide the operation interface of the APP to enter the interactive mode friend interface.  
b. Click the interactive button on the APP homepage to enter the interactive mode friend interface.  
c. Add friends  
d. On the friend interface, click the friend button at the bottom and the friend search box will appear.



Dear, you have not added any friends.


— 11 —

e. Friends search can search for corresponding registered users by gender and age, and can also search accurately by ID number, nickname, mobile phone number, and mailbox.  
f. After the search results are displayed, you click the add button on the right, and the system will send the friend request information to the target user.  
g. After the other party receives the message of the friend application, click the message button to enter the message center to view the message (the red dot means: unread), agree or reject the other party's friend application, if agreed, the mutual friend addition is successful.



— 12 —


h. After the friend is successfully added long press the friend icon to comment, delete, block out, and report the friend.  
I. Click the icon of the friend you want to interact with, the system will initiate an interactive invitation, if the other party accepts your invitation, the interactive connection is successful.  
**Note:** If the other party is not connected to the toy, your interactive interface has no control buttons at this time. The toy must be connected to the other party to have control buttons on your interactive interface. The device connection button on this interface is the Bluetooth icon in the upper right corner.



— 13 —

j. After the interactive connection is successful, the video is not turned on by default. You must first invite the other party's video and the other party agrees to open the video function before opening both parties.

**Note:** When interacting, the control button is to control the other party's device, not your own device.



— 14 —

## Attention

1. Please charge the product properly in a safe place.
2. Water-based lube is suggested as lubricant. Do not apply massage oil or hand cream to the toy surface.
3. Stop using the product, if you feel uncomfortable or you find it is no longer smooth or has sharp edges.
4. Not recommended to use it below one meter in the water.
5. Please clean it before and after use with warm water and soap (boiling water NOT allowed), or sometimes with detergent, disinfectant or 75% alcohol.
6. Keep it in cool and dry place. Avoid direct sunlight.
7. Keep it out of reach of children.
8. The product contains lithium battery. Please put it in the non-recycle bin for disposal.

## Precautions

1. Silicone-based lubrication is prohibited for this product
2. This product is adult products, minors are prohibited to use
3. When using the product, stay away from inflammation and redness wounds and broken skin wounds to avoid causing two injuries
4. If abnormalities or physical discomfort occur during use, please stop using.
5. The company will not be responsible for any medical claims caused by medical accidents if the product is not used in accordance with the instructions or is overused during use.

— 15 —